

Splash Guard - Front

Please read instructions thoroughly before starting.

Tools Required

- Socket wrench
- 7 mm Socket
- Plastic Trim Removal Tool
- Clean Cloth/Rag

Parts Required from Package Contents

Description	Quantity
Left Hand Splash Guard	1
Right Hand Splash Guard	1

Front Installation Procedure

Note: Do not use power tools to install splash guard fasteners

1. Turn front tire to provide clearance.
2. Clean and degrease body panel where splash guards are to be located.
3. Use 7 mm socket to remove screw in location (A). Retain fastener. **See Fig. 1.**
4. Use plastic trim removal tool to dislodge the existing stone protector panel clips from fender. Remove the existing stone protector. Take care not to damage paint. **See Fig. 2.**
5. Guide splash guard tabs into wheel liner slots. **See Fig. 3.**
6. Align splash guard clips with clip insertion holes and snap splash guard in. **See Fig. 3.**
7. Reinstall fastener in location (A). **See Fig. 4.**
8. Repeat procedure for the other side.
9. Guards can be cleaned with any commercially available cleaner.

NOTE: Max torque on M4.2 Screw is 3.0 N m

