



Thread: [Code List] E65/E66 Available Coding List

Thread Tools Search Thread Rate This Thread Display

02-15-2012 08:39 PM

#1

mortyx10

Member
Drives: 745i
Join Date: Oct 2011
Posts: 73
Thanks: 5
Thanked 16 Times in 7 Posts

[Code List] E65/E66 Available Coding List

Hi every one
As there is no such a list available for us E65 and E66 owners I thought I make one. This list may not be complete, so please let me know if I've missed something and I would add to the list.
I have used NCS Dummy by Revtor (Kudos for his great app) to create this list, I have tested most of them by not all.
Thanks

Video In Motion: http://www.bimmerfest.com/forums/sho...932&highlight=

Digital Speed in Dash: Thanks to macchiato66==> http://www.bmwcoding.com/showthread....al-speedometer

US Legal Disclaimer remove : Thanks to HD750Li ==> http://www.bmwcoding.com/showthread....ll=1#post22532

One Touch Turn Signal Value Change: http://www.bmwcoding.com/showthread....ll=1#post25363

CAS (Car Acces System)

Code:

SCHAERFEN/ENTSCHAERFEN LOCK AND UNLOCK
nur mit fernbedienung only with remote
schloss_und_fernbedienung with key and remote

Code:

VERRIEGELN_XKM/H_SENDER_1 AUTOMATICALLY LOCK VEHICLE WHEN EXCEEDING A CERTAIN SPEED WHEN USIN
G KEY 1
ER_KEYOUT_AUTOVR UNLOCKS DOOR LOCKS WHEN CAR STOPS

Code:

VERRIEGELUNGSSCHWELLE THRESHOLD SPEED FOR SPEED DEPENDENT VEHICLE LOCKING
wert_01 value 01 (Locks the doors as soon as the vehicle moves)
wert_02 value 02
wert_03 value 03
wert_04 value 04 (20km/h)
wert_05 value 05
wert_06 value 06

Code:

VER_AUT_X_MIN_SENDER_1 Auto lock after 2min if door not open

Code:

ZV_SELEKTIV CENTRAL LOCKING ONLY UNLOCKS DRIVER'S DOOR ON FIRST UNLOCK
aktiv active (have to press unlock 2 times to unlock all 4 doors)
nicht_aktiv not active
can also use SEL_ZV_SENDER_1 if you want to set this option for only one of your remotes and not th
e others (1 is the Remote Number)

Code:

FH_ABSCHALTKRITERIUM POWER WINDOWS BEHAVIOR AFTER IGNITION DEACTIVATED
aktiv active (Disabled)
nicht_aktiv not active (Enabled for another minute)

Code:

KOMFORTSCHLIESSUNG COMFORT CLOSING (POWER WINDOWS, SUNROOF OR CONVERTIBLE TOP)
KOMFORTOEFFNUNG COMFORT OPENING (POWER WINDOWS, SUNROOF OR CONVERTIBLE TOP)
KOMFORTSCHLIESSUNG_FB COMFORT CLOSING WITH REMOTE (POWER WINDOWS, SUNROOF OR CONVERTIBLE
TOP)
KOMFORTOEFFNUNG_FB COMFORT OPENING WITH REMOTE (POWER WINDOWS, SUNROOF OR CONVERTIBLE

HKL (Rear Lift Lid)

Code:

FUNKTION_TOEHKI Tailgate to close with the switch in the foot

Code:

FUNKTION_FBD_SCHLIESSEN_2	Tailgate close by pressing only once on the key itself
---------------------------	--

Code:

KOMFORT_SCHLIESSEN_HKL	Tailgate Close Comfort (to close the lid by pressing and holding the lock key)
KOMFORT_OEFFNEN_HKL	Tailgate Open Comfort

IHKA (Automatic Climate Control)

Code:

UMLUFT_MEMORY	REMEMBER RECIRCULATING AIR SETTING AFTER SHUTDOWN
---------------	---

Code:

LDA_B_KLIMABEREITSCHAFT	INCREASE IDLE ENGINE SPEED WHEN AIR CONDITIONING COMPRESSOR IS ACTIVATED
-------------------------	--

Code:

KLIMABETR_BEI_ZUEND_EIN_1	AIR CONDITIONING OPERATION WHEN IGNITION ACTIVATED (CKM - KEY 1) ???
---------------------------	--

KOMBI (Instrument Cluster)

Code:

BC_V_KORREKTUR	ON-BOARD COMPUTER (OBC) - ANALOGUE OR HEAD-UP DISPLAY (HUD) SPEED CORRECTION [AKTIV: CORRECTED SPEED, NICHT_AKTIV: TRUE SPEED]
nicht_aktiv	not active
aktiv	active

Code:

CC_GURTWARNUNG	CHECK CONTROL (CC) - SEAT BELT WARNING
nicht_aktiv	not active
gong	
text	
gong_text	

Code:

CC_ZUENDSCHLUESSEL	CHECK CONTROL (CC) - IGNITION KEY
nicht_aktiv	not active
aktiv	active

Code:

CC_TEMPERATURWARNUNG	CHECK CONTROL (CC) - TEMPERATURE WARNING
nicht_aktiv	not active
aktiv	active

Code:

WARNUNG_GESCHW_LIMIT	SPEED LIMIT WARNING
nicht_aktiv	not active
120_km/h	120 kilometers per hour

Code:

TANK_SCHWELLE_RESERVE	FUEL TANK RESERVE THRESHOLD
8_l	8 liters
10_l	10 liters
12_l	12 liters

MMIGT (Multimedia/Idrive)

Code:

FAHRZEUGTYP_MMI	(in case retrofitting another country's MMI unit)
ece_rl	europa (left-hand drive)
ece_rl	europa (right-hand drive)
us_rl	US (Left-hand drive)

Code:

WAHLBARE_SPRACHE_1	Language Selection (can set up to 6 languages)
nicht_aktiv	not active
deutsch	german
englisch	english

us	usa
spanisch	spanish
italienisch	italian
franzoesisch	french
flaemisch	flemish
niederlande	the netherlands
arabisch	arabic
china_trad	china (traditional)
china_simp	china (simplified)
koreanisch	korean
japan	japan

Code:

SPRACHE 1	LANGUAGE (CKM - KEY 1) (can set this option for up to 4 keys)
nicht_aktiv	not active
deutsch	german
englisch	english
us	usa
spanisch	spanish
italienisch	italian
franzoesisch	french
flaemisch	flemish
niederlande	the netherlands
arabisch	arabic
china_trad	china (traditional)
china_simp	china (simplified)
koreanisch	korean
japan	japan
sprache_o	
sprache_p	

Code:

RDC_VERBAUT	TIRE PRESSURE CONTROL (RDC) - INSTALLED
nicht_aktiv	not active
aktiv	active

Code:

OELSTAND	ENGINE OIL LEVEL
nicht_aktiv	not active
aktiv	active

Code:

LETZT_VERW_SCHLUESSEL	Last Key used (to check the remote key number)
schlüssel1	key 1
schlüssel2	key 2
schlüssel3	key 3
schlüssel4	key 4

Code:

Following options are most useful when retrofitting:

ASK_LAUFWERK	ASK UNIT
tape	
cd	
minidisk	
AMFM/TUNER	AM/FM
single_tuner	single tuner
double_tuner	double tuner
CD_WECHSLER	CD CHANGER
nicht_aktiv	not active
aktiv	active
MULTIMEDIA_CHANGER	
nicht_aktiv	not active
aktiv	active
VIDEOMODUL	VIDEO MODULE
nicht_aktiv	not active
aktiv	active
TV_VIDEO_ABSCHALTUNG	
aktiv	active
nicht_aktiv	not active
TOP_HIFI	TOP HIFI
nicht_aktiv	not active
aktiv	active
SITZHEIZUNG	SEAT HEATING
nicht_aktiv	not active
aktiv	active
NAVIGATION_VERBAUT	NAVIGATION INSTALLED
nicht_aktiv	not active
aktiv	active

TMBT/TMFT (Doors modules)

Code:

FH_BEIFAHRERTUER_TIPP_AUF	ONE-TOUCH OPENING PASSENGER'S POWER WINDOW
aktiv	active
nicht_aktiv	not active
FH_BEIFAHRERTUER_TIPP_ZU	ONE-TOUCH CLOSING PASSENGER'S POWER WINDOW
aktiv	active
nicht_aktiv	not active

Code:

BEIKLAPPEN_B_KOMFORTSCHL	COMFORT FOLDING (MIRRORS) (Both TMBT and TMFT modules must be coded)
nicht_aktiv	not active
aktiv	active

Code:

```
SPIEGELMEMORY          OUTSIDE MIRROR MEMORY
aktiv                  active
nicht_aktiv           not active
```

Last edited by mortyx10; 04-14-2012 at 09:07 PM.

Thanks

Reply

Reply With Quote

The Following User Says Thank You to mortyx10 For This Useful Post:

leeshau (09-15-2012)

02-15-2012 08:39 PM

#2

mortyx10

Member

Drives:: 745i
 Join Date: Oct 2011
 Posts: 73
 Thanks: 5
 Thanked 16 Times in 7 Posts

LMA (Light Module)

Code:

```
FL_UND NSW NICHT_GLEICHZ FRONT FOG LIGHTS NOT SIMULTANEOUSLY WITH HIGH BEAMS
nicht_aktiv             not active
aktiv                   active
```

Code:

```
TAGFAHRLICHT_ECE       DAYTIME RUNNING LIGHTS (EUROPE)
nicht_aktiv             not active
aktiv                   active
```

Code:

```
MIND_ANZ_ZYKL_TIPP_BLK ONE-TOUCH TURN SIGNAL FUNCTION
wert_01                 value 01 (1 signal)
wert_02                 value 02 (3 signals)
```

Code:

```
QUITT_BLK_SICHERN      VISUAL LOCK WITHOUT ANTI-THEFT ALARM SYSTEM
nicht_aktiv            not active
aktiv                  active (turn signals blink when lock the vehicle)

QUITT_BLK_ENTSICHERN   VISUAL UNLOCK WITHOUT ANTI-THEFT ALARM SYSTEM
nicht_aktiv            not active
aktiv                  active
```

Code:

```
SIDEMARKER_US          PARKING LIGHTS ON WHEN HEADLIGHTS ACTIVATED (USA)
nicht_aktiv            not active
aktiv                  active
```

Code:

```
HEIMLEUCHTEN          FOLLOW-ME-HOME LIGHTS (ACTIVATED BY FLASHING HIGH BEAMS WITH IGNITION O
FF) [1: OFF, 2: ACTIVE]
wert_01                value 01
wert_02                value 02
wert_03                value 03
wert_04                value 04
wert_05                value 05
HEIMLEUCHTEN_BL       FOLLOW-ME-HOME LIGHTS - TURN SIGNALS
nicht_aktiv            not active
aktiv                  active
HEIMLEUCHTEN_NSL      FOLLOW-ME-HOME LIGHTS - FOG LIGHTS - REAR
nicht_aktiv            not active
aktiv                  active
HEIMLEUCHTEN_NSW      FOLLOW-ME-HOME LIGHTS - FOG LIGHTS - FRONT
nicht_aktiv            not active
aktiv                  active
HEIMLEUCHTEN_SL       FOLLOW-ME-HOME LIGHTS - PARKING LIGHTS
nicht_aktiv            not active
aktiv                  active
HEIMLEUCHTEN_RFS      FOLLOW-ME-HOME LIGHTS - REVERSING LIGHTS
nicht_aktiv            not active
aktiv                  active
HEIMLEUCHTEN_FL       FOLLOW-ME-HOME LIGHTS - HIGH BEAMS
nicht_aktiv            not active
aktiv                  active
HEIMLEUCHTEN_RL       FOLLOW-ME-HOME LIGHTS - TAIL LIGHTS
nicht_aktiv            not active
aktiv                  active
HEIMLEUCHTEN_AL       FOLLOW-ME-HOME LIGHTS - LOW BEAMS
nicht_aktiv            not active
```

Code:

```
KALTUEBERWACHUNG_NSW_R COLD MONITORING - FOG LIGHTS - FRONT RIGHT
KALTUEBERWACHUNG_NSW_L COLD MONITORING - FOG LIGHTS - FRONT LEFT
KALTUEBERWACHUNG_SL_V_R COLD MONITORING - PARKING LIGHTS OR ANGEL EYES - FRONT RIGHT
KALTUEBERWACHUNG_SL_V_L COLD MONITORING - PARKING LIGHTS OR ANGEL EYES - FRONT LEFT
KALTUEBERWACHUNG_AL_R  COLD MONITORING - LOW BEAMS - RIGHT
```

KALTUEBERWACHUNG_AL_L	COLD MONITORING - LOW BEAMS - LEFT
KALTUEBERWACHUNG_FL_R	COLD MONITORING - HIGH BEAMS - RIGHT
KALTUEBERWACHUNG_FL_L	COLD MONITORING - HIGH BEAMS - LEFT
KALTUEBERWACHUNG_BL_R	COLD MONITORING - BRAKE LIGHTS - RIGHT
KALTUEBERWACHUNG_BL_L	COLD MONITORING - BRAKE LIGHTS - LEFT
KALTUEBERW_BLK_V_R_Z	COLD MONITORING - TURN SIGNALS - FRONT RIGHT
KALTUEBERW_BLK_V_L_2	COLD MONITORING - TURN SIGNALS - FRONT LEFT
KALTUEBERWACHUNG_BLK_H_R	COLD MONITORING - TURN SIGNALS - REAR RIGHT
KALTUEBERWACHUNG_BLK_H_L	COLD MONITORING - TURN SIGNALS - REAR LEFT
KALTUEBERWACHUNG_BLK_V_R	COLD MONITORING - TURN SIGNALS - FRONT RIGHT
KALTUEBERWACHUNG_BLK_V_L	COLD MONITORING - TURN SIGNALS - FRONT LEFT
KALTUEBERWACHUNG_NSL_L	COLD MONITORING - FOG LIGHTS - REAR LEFT
KALTUEBERWACHUNG_KZL_R	COLD MONITORING - LICENSE PLATE LIGHTS - RIGHT
KALTUEBERWACHUNG_KZL_L	COLD MONITORING - LICENSE PLATE LIGHTS - LEFT
KALTUEBERW_RL_BL_2_R	COLD MONITORING - TAILS LIGHTS - RIGHT 2
KALTUEBERW_RL_BL_2_L	COLD MONITORING - TAILS LIGHTS - LEFT 2
KALTUEBERW_RL_BL_1_R	COLD MONITORING - TAILS LIGHTS - RIGHT 1
KALTUEBERW_RL_BL_1_L	COLD MONITORING - TAILS LIGHTS - LEFT 1
KALTUEBERWACHUNG_BLM_1	COLD MONITORING - BRAKE LIGHTS - THIRD 1
KALTUEBERWACHUNG_BLK_Z_R	COLD MONITORING - TURN SIGNALS - SIDE RIGHT
KALTUEBERWACHUNG_BLK_Z_L	COLD MONITORING - TURN SIGNALS - SIDE LEFT
KALTUEBERWACHUNG_RFS_R	COLD MONITORING - REVERSING LIGHTS - RIGHT
KALTUEBERWACHUNG_RFS_L	COLD MONITORING - REVERSING LIGHTS - LEFT
KALTUEBERWACHUNG_NSL_R	COLD MONITORING - FOG LIGHTS - REAR RIGHT

Code:

WARMUEBERWACHUNG_NSW_R	HOT MONITORING - FOG LIGHTS - FRONT RIGHT
WARMUEBERWACHUNG_NSW_L	HOT MONITORING - FOG LIGHTS - FRONT LEFT
WARMUEBERWACHUNG_SL_V_R	HOT MONITORING - PARKING LIGHTS OR ANGEL EYES - FRONT RIGHT
WARMUEBERWACHUNG_SL_V_L	HOT MONITORING - PARKING LIGHTS OR ANGEL EYES - FRONT LEFT
WARMUEBERWACHUNG_AL_R	HOT MONITORING - LOW BEAMS - RIGHT
WARMUEBERWACHUNG_AL_L	HOT MONITORING - LOW BEAMS - LEFT
WARMUEBERWACHUNG_FL_R	HOT MONITORING - HIGH BEAMS - RIGHT
WARMUEBERWACHUNG_FL_L	HOT MONITORING - HIGH BEAMS - LEFT
WARMUEBERWACHUNG_BL_R	HOT MONITORING - BRAKE LIGHTS - RIGHT
WARMUEBERWACHUNG_BL_L	HOT MONITORING - BRAKE LIGHTS - LEFT
WARMUEBERW_BLK_V_R_Z	HOT MONITORING - TURN SIGNALS - FRONT RIGHT
WARMUEBERW_BLK_V_L_2	HOT MONITORING - TURN SIGNALS - FRONT LEFT
WARMUEBERWACHUNG_BLK_H_R	HOT MONITORING - TURN SIGNALS - REAR RIGHT
WARMUEBERWACHUNG_BLK_H_L	HOT MONITORING - TURN SIGNALS - REAR LEFT
WARMUEBERWACHUNG_BLK_V_R	HOT MONITORING - TURN SIGNALS - FRONT RIGHT
WARMUEBERWACHUNG_BLK_V_L	HOT MONITORING - TURN SIGNALS - FRONT LEFT
WARMUEBERWACHUNG_NSL_L	HOT MONITORING - FOG LIGHTS - REAR LEFT
WARMUEBERWACHUNG_KZL_R	HOT MONITORING - LICENSE PLATE LIGHTS - RIGHT
WARMUEBERWACHUNG_KZL_L	HOT MONITORING - LICENSE PLATE LIGHTS - LEFT
WARMUEBERW_RL_BL_2_R	HOT MONITORING - TAILS LIGHTS - RIGHT 2
WARMUEBERW_RL_BL_2_L	HOT MONITORING - TAILS LIGHTS - LEFT 2
WARMUEBERW_RL_BL_1_R	HOT MONITORING - TAILS LIGHTS - RIGHT 1
WARMUEBERW_RL_BL_1_L	HOT MONITORING - TAILS LIGHTS - LEFT 1
WARMUEBERWACHUNG_BLM_1	HOT MONITORING - BRAKE LIGHTS - THIRD 1
WARMUEBERWACHUNG_BLK_Z_R	HOT MONITORING - TURN SIGNALS - SIDE RIGHT
WARMUEBERWACHUNG_BLK_Z_L	HOT MONITORING - TURN SIGNALS - SIDE LEFT
WARMUEBERWACHUNG_RFS_R	HOT MONITORING - REVERSING LIGHTS - RIGHT
WARMUEBERWACHUNG_RFS_L	HOT MONITORING - REVERSING LIGHTS - LEFT
WARMUEBERWACHUNG_NSL_R	HOT MONITORING - FOG LIGHTS - REAR RIGHT

PDC (Park Distance Control)

Code:

ANHAENGERKUPPLUNG	WHEN TRAILER WIRE ATTACHED REAR PARK DISTANCE CONTROL (PDC) DEACTIVATED
nicht_aktiv	not active
aktiv	active

Code:

PDC_AKTIV/DEAKTIV	PARK DISTANCE CONTROL (PDC) - ACTIVATED/DEACTIVATED
weg_geschw	
rueckwaertsgang	reverse gear (PDC only with reverse gear)

Code:

TONGEBER_VORN	TONE GENERATOR FRONT
lautsprecher	loudspeaker
gong	
TONGEBER_HINTEN	TONE GENERATOR REAR
lautsprecher	loudspeaker
gong	

PMA (Interior Light)

Code:

INNENLICHT_AN_MEHRFACH_ZV	PRESSING REMOTE LOCK BUTTON TWICE TURNS ON INTERIOR LIGHTS
aktiv	active
nicht_aktiv	not active

Code:

SOFT_ON/OFF	SOFTLY FADE ON/OFF INTERIOR LIGHTS
aktiv	active
nicht_aktiv	not active

Code:

IB_EIN_SCHLOSS_ENTRIEGELN	INTERIOR LIGHTS TURN ON WHEN UNLOCKED
aktiv	active
nicht_aktiv	not active

RLS Module**Code:**

```

FLC_SCHWELLMERT_SATZ      AUTOMATIC DRIVING LIGHTS SENSITIVITY
wert_01                   value 01
wert_02                   value 02
wert_03                   value 03

```

SHD (Sunroof Module)**Code:**

```

REGENSCHLIESSENTILT      CLOSE TILTED SUNROOF WITH AUTOMATIC RAIN SENSOR (RL) WIPER OPERATION
aktiv                    active
nicht_aktiv              not active

```

Code:

```

REGENSCHLIESSEN          CLOSE SUNROOF WITH AUTOMATIC RAIN SENSOR (RL) WIPER OPERATION
aktiv                    active
nicht_aktiv              not active

```

Code:

```

SCHIEBEHEBEDACH_TIPP_ZU  ONE-TOUCH CLOSING SUNROOF
aktiv                    active
nicht_aktiv              not active

SCHIEBEHEBEDACH_TIPP_AUF ONE-TOUCH OPENING SUNROOF
aktiv                    active
nicht_aktiv              not active

SCHIEBEHEBEDACH_TIPP_SENK ONE-TOUCH LOWER SUNROOF
aktiv                    active
nicht_aktiv              not active

SCHIEBEHEBEDACH_TIPP_HEB ONE-TOUCH RAISE SUNROOF
aktiv                    active
nicht_aktiv              not active

```

IM (ipers)**Code:**

```

STANDRUECKSCHALTUNG      WIPERS RETURN TO INTERVAL WHEN CAR STOPPED
aktiv                    active
nicht_aktiv              not active

```

ASK (Audio System Controller)**Code:**

```

ABSENK_ENTERTAINMENT_PDC MUTE ENTERTAINMENT WHEN PARK DISTANCE CONTROL (PDC) ACTIVATED ???
standard
ein                       on

```

Code:

```

VOLUME_DELTA_PDC_ENTER
standard
max3
max2
max1
min1
min2
min3

```

Last edited by mortyx10; 02-24-2012 at 12:39 AM.

Thanks

Reply

Reply With Quote

The Following User Says Thank You to mortyx10 For This Useful Post:

leeshau (09-15-2012)

02-15-2012 08:48 PM

#3

unspecialme®

Senior Member



Drives: E46 323
 Join Date: May 2011
 Posts: 109
 Thanks: 5

Do you have code for TV in motion ????

Thanked 2 Times in 2 Posts



Thanks

Reply

Reply With Quote

02-15-2012 08:58 PM

#4

mortyx10

Member



Drives:: 745i
 Join Date: Oct 2011
 Posts: 73
 Thanks: 5
 Thanked 16 Times in 7 Posts

as far as I know it is not possible via regular coding nor nettodat coding. I am trying to do so but no luck yet. another thing I'd like to do is MP3 but again e65 is not easy as others. at the moment I'm working to get the angel lights brighter, VIM, and MP3, but as I said e65 is not that easy to work with.

Thanks

Reply

Reply With Quote

02-15-2012 11:05 PM

#5

ehssan

Moderator



Join Date: Mar 2011
 Posts: 1,186
 Thanks: 288
 Thanked 313 Times in 103 Posts

MP3 is easy : if you are not sure which module is MP3 option available , look at the full trc file , you will find MP3 , enable it and recode the whole car ..

VIM is secret ,

angel eyes to become brighter ,, this is the maximum you can get ,

Thanks

Reply

Reply With Quote

02-16-2012 04:11 AM

#6

mortyx10

Member



Drives:: 745i
 Join Date: Oct 2011
 Posts: 73
 Thanks: 5
 Thanked 16 Times in 7 Posts

Hi ehssan, Thanks for the input.

I've done what you mentioned for mp3 but it doesn't work, the thing is my ASK unit is MD not CD so I try to play via my cd changer, however I know other people who has tried with no luck either.

for the angel eyes, you saying it's not possible via nettodat coding and custom voltages?

and finally the big secret can you at least give us a hint? like is it done via coding? nettodat? disassembly? ... (you can pm me if you like)
 Thank you again.

Thanks

Reply

Reply With Quote

02-16-2012 06:05 AM

#7

piers1989

Junior Member



Drives:: e65 745i
 Join Date: Feb 2012
 Posts: 8
 Thanks: 0
 Thanked 0 Times in 0 Posts

I've just coded some changes to my car and my thanks go to you for this list 😊

How do I get the CAS module to reset?

I've made a couple of changes to it and I've read them back out to make sure they were uploaded okay, which they are, but they aren't taking effect.

I assume this is because the CAS stays turned on even when the car is "off".

Thanks

Reply

Reply With Quote

02-16-2012 07:29 PM

#8

s5002745Li

Junior Member



Drives:: 2003 BMW 745Li
 Join Date: Feb 2012
 Posts: 7
 Thanks: 0
 Thanked 0 Times in 0 Posts

I might have the same problem as piers1989, but I'm trying to turn off RDC. I have disabled it in MMIGT, but no effect. I also found RDC_ALIVE in KOMBI, and I disabled that as well, but no effect. Is there something else I have to do, like pull a fuse like other car versions?

Thanks

Reply

Reply With Quote

02-16-2012 07:33 PM

#9

s5002745Li

Junior Member



Drives:: 2003 BMW 745Li
 Join Date: Feb 2012
 Posts: 7
 Thanks: 0
 Thanked 0 Times in 0 Posts

By the way, it occurs to me that since this is in the MMI module, all it's doing is turning off the access to RDC, although it can still throw faults. I was hoping turning it off in KOMBI would prevent it from reading the faults.

Anyone know the VO code for RDC?

Thanks

Reply

Reply With Quote

02-16-2012 08:38 PM

#10

dtbimmer

Member

Drives:: BMWs
Join Date: Mar 2011
Location: USA
Posts: 72
Thanks: 3
Thanked 7 Times in 6 Posts

unplug the rdc module behind the glovebox after coding

Thanks

Reply

Reply With Quote

+ Reply to Thread

Page 1 of 10 1 2 3 ... Last

Quick Navigation E6x Top

Quick Reply

Empty text area for quick reply.

Post Quick Reply Go Advanced

<Previous Thread | Next Thread>

Tags for this Thread

None

[View Tag Cloud](#)

[Add / Edit Tags](#)

Posting Permissions

You may post new threads **BB code** is On
You may post replies **Smilies** are On
You may post attachments **[IMG]** code is On
You may edit your posts HTML code is Off
[Forum Rules](#)

[Contact Us](#) [BMW Coding Archive](#) [Top](#)

[Donate](#)

All times are GMT -8. The time now is 03:33 PM.

Powered by vBulletin® Version 4.1.6
Copyright © 2012 vBulletin Solutions, Inc. All rights reserved.

This document was created with Win2PDF available at <http://www.win2pdf.com>.
The unregistered version of Win2PDF is for evaluation or non-commercial use only.
This page will not be added after purchasing Win2PDF.