



Has your furnace quit working? These leading 5 furnace problems and their simple services may help to get it working.

Having difficulty with your heating system? You're not alone. Thankfully, lots of issues have simple DIY fixes. The primary step: Inspect whether your HVAC system has power. You do not wish to have a service [heating and cooling near me](#)

tech concerned your house just to turn a switch at the breaker box. If power isn't the problem, inspect other possible glitches before calling for service.

# 1 ISSUE: Thermostat isn't working.

LIKELY CULPRIT: If your heat isn't coming on at all, attempt altering the batteries in the thermostat, if it has batteries. While you're at it, offer the thermostat a great cleaning inside with a little paintbrush.

You can also attempt to reboot it. With the thermostat set to Heat, turn the temperature level to about 60°. Then, turn the breaker switch off for 30 seconds and turn it back on Still nothing? Employ a professional.

# 2 PROBLEM: System not turning on.

LIKELY PERPETRATOR: Inspect the emergency situation shutoff switch for the heating system. It might be at the entrance to the heating system closet, at the top of the basement stairs, or on the heater. It may have a red switch plate. if someone switched it off, the heater will not work.

# 3 ISSUE: Dirty filter

LIKELY PERPETRATOR: Not switching out an old filter can cause a host of problems, not to mention increasing your energy bill. To guarantee your heater doesn't work overtime, alter your filter each to two months. Here's how: Switch off your furnace, find the filter, remove the old one (and remember of the size), replace it and turn the heater back on.

# 4 PROBLEM: Heater isn't firing up

MOST LIKELY PERPETRATOR: Does your furnace click as though it will switch on, however then go quiet and never ever start? If you've examined the power, examined the thermostat and changed the filter, the pilot burner or the ignition sensing unit is most likely the issue. To fix it, begin by switching off the gas to your furnace. Then remove

the front panel and find the igniter or ignition sensor, which is usually near the burners. Snap a photo of the sensing unit to advise you of how it's attached and after that remove the ignition sensing unit. Rub it with steel wool to get rid of residue, taking care to not damage it. Then put it back exactly as you found it and replace the panel before turning the gas back on. If you have any doubt about this job, play it safe and contact the pros.

# 5 ISSUE: Heating system keeps tripping the breaker

LIKELY PERPETRATOR: If your heater keeps tripping the breaker or blowing the fuse when the heat kicks in, it's more than likely an electrical problem. To keep you and your family safe, contact the pros to diagnose the cause.

While numerous common heater concerns can be repaired without employing the specialists, it is very important to have your heating system expertly serviced when a year, particularly if you're not comfy carrying out a few of the needed upkeep tasks yourself.

<http://edition.cnn.com/search/?text=hvac>